


How to verify Optimus is turned on in your Alienware

R4

Before installing your New GPU, make sure you are running in optimus mode.

Go into device manager and verify that there are 2 cards listed.
One being the intel, and the other being your current card.




If you DO NOT have both listed, press **FN+F7**, and the system will request a reboot. Then they both will be there.

R5

Before installing your New GPU, make sure you are running in optimus mode.

Go into device manager and verify that there are 2 cards listed.
One being the intel, and the other being your current card.



If you DO NOT have both listed, press **FN+F5**, and the system will request a reboot. Then they both will be there.